



## Assembly instructions for your Winphotec flash brackets

The flash brackets are sent to you in a pre-aligned condition. Needless to say, it is up to the customer, how he or she wants to then adjust the friction of the individual arms of the equipment. For this you need to use the allen key, which is also included in the delivery. With the back of the screw nut, you need to turn the 2mm long counter stud screw to the left approximately once. By turning the big knurled nut clockwise, the friction can be increased or alternatively reduced or completely undone by turning it anti-clockwise.

**Important:** The screws opposite one another need to finally be tightened by hand, or else a counter-effect will not be achieved. Following this, the previously loosened rearward stud screw, needs to be tightened once again, by turning it clockwise. By doing this, the newly adjusted friction is fixated. Attached to the support screws, are retral felt pads, which are perforated in the middle. The same procedure, as described above, needs to be repeated here.

If you have any further questions, do not hesitate to put your questions towards our team.